

Lab: Using Archive Utilities on Linux

Objective

- Learn how to create and extract archives using common Linux tools.
- Understand how to compress directories and files with different utilities:
 - **zip/unzip**
 - **tar** (with no compression, gzip, bzip2, and xz)
 - **cpio** (combined with gzip for compression)

Prerequisites

- A Linux system with a terminal.
- Installation of utilities (most are pre-installed on many distributions). If needed:

```
sudo apt-get install zip unzip tar gzip bzip2 xz-utils cpio
```

Part 1: Preparing a Sample Directory

1. Create a Working Directory

Open your terminal and create a new directory named labfiles:

```
mkdir labfiles
```

2. Populate the Directory

Create several text files and a subdirectory with a file inside. This structure will serve as your sample data.

```
cd labfiles
```

```
echo "This is the first file." > file1.txt
```

```
echo "This is the second file." > file2.txt
```

```
echo "This is the third file." > file3.txt
```

```
mkdir subdir
```

```
echo "This file is inside a subdirectory." > subdir/subfile.txt
```

```
cd ..
```

Your directory structure should now look like this:

```
labfiles/  
├── file1.txt  
├── file2.txt  
├── file3.txt  
└── subdir/  
    └── subfile.txt
```

Part 2: Archiving with zip and unzip

1. Create a zip Archive

Archive the entire labfiles directory into a file called labfiles.zip:

```
zip -r labfiles.zip labfiles
```

- The -r flag ensures that directories are processed recursively.

2. Extract the Zip Archive

Create a new directory to extract the contents and unzip the archive:

```
mkdir labfiles_zip_extract
```

```
unzip labfiles.zip -d labfiles_zip_extract
```

3. Verify the Extraction

Check the labfiles_zip_extract directory to confirm that the file structure matches the original.

Part 3: Creating tar Archives

A. Uncompressed tar Archive

1. Create an Uncompressed tar Archive

Use tar to create an archive named labfiles.tar:

```
tar -cvf labfiles.tar labfiles
```

- **Flags:**
 - -c: Create a new archive.
 - -v: Verbosely list files processed.
 - -f: Specifies the filename.

2. Extract the Uncompressed tar Archive

Create an extraction directory and extract the archive:

```
mkdir labfiles_tar_extract
```

```
tar -xvf labfiles.tar -C labfiles_tar_extract
```

B. Compressed tar Archive with gzip

1. Create a gzip Compressed tar Archive

Create an archive with gzip compression:

```
tar -czvf labfiles.tar.gz labfiles
```

- Flag -z tells tar to compress the archive using gzip.

2. Extract the gzip Compressed tar Archive

Extract into a new directory:

```
mkdir labfiles_tar_gz_extract
```

```
tar -xzvf labfiles.tar.gz -C labfiles_tar_gz_extract
```

C. Compressed tar Archive with bzip2

1. Create a bzip2 Compressed tar Archive

Use the following command:

```
tar -cjvf labfiles.tar.bz2 labfiles
```

- Flag -j instructs tar to use bzip2 compression.

2. Extract the bzip2 Compressed tar Archive

Extract the archive:

```
mkdir labfiles_tar_bz2_extract
```

```
tar -xjvf labfiles.tar.bz2 -C labfiles_tar_bz2_extract
```

D. Compressed tar Archive with xz

1. Create an xz Compressed tar Archive

Create the archive as follows:

```
tar -cJvf labfiles.tar.xz labfiles
```

- **Flag -J** tells tar to use xz compression.

2. Extract the xz Compressed tar Archive

Extract the archive:

```
mkdir labfiles_tar_xz_extract
```

```
tar -xJvf labfiles.tar.xz -C labfiles_tar_xz_extract
```

3. Verify Each Extraction

Ensure all the extracted directories (labfiles_tar_extract, labfiles_tar_gz_extract, labfiles_tar_bz2_extract, and labfiles_tar_xz_extract) have the same structure as the original labfiles directory.

Part 4: Archiving with cpio (Combined with gzip)

1. Create a cpio Archive of Specific Files

Use the find command to list all .txt files in labfiles and create an archive with cpio:

```
find labfiles -type f -name "*.txt" | cpio -ov > labfiles.cpio
```

- **Flags for cpio:**
 - -o: Create an archive.
 - -v: Verbose output.

2. Compress the cpio Archive with gzip

Compress the archive:

```
gzip labfiles.cpio
```

This command produces labfiles.cpio.gz.

3. Extract the cpio Archive

Create an extraction directory and extract the gzip-compressed cpio archive:

```
mkdir labfiles_cpio_extract
```

```
gunzip -c labfiles.cpio.gz | (cd labfiles_cpio_extract && cpio -idmv)
```

- **Notes:**
 - gunzip -c decompresses the archive to standard output.
 - The pipe | passes the decompressed data into cpio for extraction.

- -i: Extract files.
- -d: Create directories as needed.
- -m: Preserve modification times.
- -v: Verbose output.

4. Verify the cpio Extraction

Check the `labfiles_cpio_extract` directory to ensure that all .txt files have been extracted correctly.

Wrap-Up and Clean-Up

- **Review:** Ensure you understand each command and its flags. Verify that the extracted directories match your original labfiles structure.
- **Clean Up (Optional):** Remove temporary archives and extraction directories if needed:

```
rm -rf labfiles_zip_extract labfiles_tar_extract labfiles_tar_gz_extract labfiles_tar_bz2_extract  
labfiles_tar_xz_extract labfiles_cpio_extract
```

```
rm labfiles.zip labfiles.tar labfiles.tar.gz labfiles.tar.bz2 labfiles.tar.xz labfiles.cpio.gz
```

- **Extend the Lab:** Experiment with additional options such as excluding files from tar archives (`--exclude`) or using encryption with zip (`-e`). Try modifying files in the original directory and re-running backup commands to see how updates are handled.

Conclusion

In this lab, you learned how to:

- Create and extract archives using **zip** and **unzip**.
- Use **tar** in its uncompressed form and combined with different compression tools: **gzip**, **bzip2**, and **xz**.
- Use **cpio** together with **gzip** to archive specific files.